

DESICCANT APPLICATION FORMULA

MIL-P-116 Application: General Dry Packaging

WHAT YOU NEED TO KNOW:
Bag Cubic Inches (L x W x H)

DESICCANT RATIO FORMULA:
Units = $0.011 \times$ Bag Cubic Inches

EXAMPLE:
8" x 10" x 5" Barrier Bag = 400 cubic inches

APPLY FORMULA:
 $0.011 \times 400 \text{ cu.in.} = 4.4$
Use 5 units of desiccant (always round up)

